



INSTRUCTIONS & WARRANTY

Clubmaster ICONIC

BRISTON 

INTRODUCTION

Congratulations for the acquisition of your BRISTON watch, and thank you for your confidence.

The Clubmaster ICONIC is a classic & pure watchmaking interpretation of the automatic watch in the BRISTON collection. True icon in terms of design, this model is distinguished by the opening of its case-back revealing the beauty of the automatic movement equipped with a rotor decorated with «Côte de Genève».

We invite you to consult the operating instructions and hope your BRISTON timepiece brings you great enjoyment.

INSTRUCTIONS

The Clubmaster ICONIC watch must be serviced regularly in order to work correctly.

The time left between services will vary depending on the model, climate and amount of care you take of your watch.

> Temperature: avoid temperatures exceeding 0/100°F;

-20/+40°C and extreme conditions.

> Avoid prolonged exposure to sun, water and steam to prevent distortion and color fading.

> Avoid contact with alcohol, perfume, detergents and cosmetic products to prevent corrosion.

> Make sure your winder is well positioned against the case to prevent any water entering the mechanism.

> Check your model's ATM level so that you know how deep you can use it. (5 ATM = 50 meters of depth – 165 feet). You can wash your hands but not swim with your watch.

To remind, your BRISTON watch can only be used in the following conditions: washing hands & shower. DO NOT USE FOR DIVING ACTIVITY or other WATER SPORT.

> Please also note that leather straps are not suitable for aquatic activities.

ACCURACY

Manually-wound or automatic mechanical watches

The precision of watch models with mechanical movements is determined by the balance. This oscillates at a rate of 21,600 vibrations per hour. Despite all the care that we have taken on building and assembling your watch, its accuracy is subject to the influence of gravity, magnetic fields, impacts and ageing of the oils. The precision of a watch is measured by its regularity of rate in various positions. Your individual temperament and your activities could be the cause of slight irregularities.

If you observe a discrepancy in the running of your watch, we advise you to entrust it to an authorized BRISTON retailer who will make the necessary adjustments.

Technical characteristics

- > Mechanical movement with automatic winding, calibers NH35A or NH38A
- > 21'600 oscillations/hour (3 Hz)
- > Jewels: 24
- > Power reserve: up to 41 hours
- > Bidirectional rotor with "Côte de Genève" decoration

SETTING OF YOUR AUTOMATIC BRISTON WATCH



First time using your BRISTON watch

Maintain the crown against the case & make several turns (around 30) clockwise to run the watch & rewind it manually. The central seconds hand is starting.

Please note that your watch will automatically run when you wear it.

SETTING OF YOUR BRISTON (ICONIC DATE)



a) Setting the time

1. Gently pull the winder out to the 2nd position.
2. The movement is now stopped (« stop second » function). Turn the crown to set the hour and minute hands until the desired time.
3. The second hand starts again when the winder is pushed back into its normal position against the case.



b) Setting the date

1. Gently pull the winder out to the 1st position.
2. Turn the winder anticlockwise to set the date.

Warning: never make a date correction when the watch shows a time between 10 PM and 2 AM. the automatic mechanism of date change is activated during this period of time and the movement could be damaged.

3. Return the winder to its normal position. The watch is now working again.

SETTING OF YOUR BRISTON (ICONIC OPEN)



a) Setting the time

1. Gently pull the winder out to the 1st position.
2. The movement is now stopped (« stop second » function). Turn the crown to set the hour and minute hands until the desired time.
3. The second hand starts again when the winder is pushed back into its normal position against the case.

WARRANTY

The movement of a mechanical watch requires regular maintenance (servicing, lubrication, etc.) to ensure a long operating life. Should your watch need servicing or repairs, please send it, together with its guarantee certificate, to the authorized BRISTON retailer who sold it to you.

Thanks to the BRISTON warranty, any BRISTON watch that has to be repaired due to a manufacturing fault will be repaired free of charge. The warranty certificate must be completed, stamped and signed by the authorized BRISTON retailer.

The following damages or cases are not covered by the BRISTON warranty:

- > Any damage resulting from inadequate or insufficient care, an accident or any normal use;
- > the watch dial, the strap, the case, the crystal, the strap links and any other accessory sold with the watch or contained in the packaging;

> Any complaint associated with damage or injury caused directly or indirectly by wearing the BRISTON watch;

> Loss of water resistance following exposure to water at a pressure greater than 50 meters OR loss of water resistance after using the watch or crown under water OR damage following the use of alcohol or detergents OR significant damage or corrosion on the watch.

BRISTON will send a bill for its fees to clients claiming additional services or who are unable to present a valid warranty certificate.

Every BRISTON timepiece comes with a 2-YEAR INTERNATIONAL WARRANTY against defects in material and manufacturing. This warranty covers all parts except the above mentioned elements.

The information above are registered as technical information and will be subject to approval from BRISTON. All cases not covered by the above list will be dealt with, accordingly.

The information contained in this document belongs to BRISTON and may not be reproduced without its authorization.

We will not be responsible for any consequential damages arising from the ownership or use of timepiece.

Please include your watch, the completed warranty form (with stamp of the shop) together with your proof of purchase clearly stating the nature of the fault.

The limited warranty is obsolete if the defect is discovered to be caused by abuse or tampering with the watch.

Please first contact the nearest authorized BRISTON dealer who will proceed with the return and please read or contact the Customer Service by e-mail: sc@briston-watches.com

www.briston-watches.com

